

TRUEPREP ANTICORROSIVE PRIMER

TDS55-720UP

DESCRIPTION	A single pack primer based on alkyd resins and anti-corrosive pigments. Specially developed for direct application to new and weathered galvanised steel. Effectively adheres itself to galvanised steel and stops zinc corrosion. Also suitable for use on Zincalume.
TYPICAL USES	Ideal for the following substrates: • Galvanised Steel • Gutters • Flashings • Downpipes • Pre-painted Steel • Corrugated Iron • Zincalume
PERFORMANCE	Excellent adhesion to Galvanised Steel and Zincalume. Suitable for use over lightly rusted Galvanised steel and Zincalume. Overcoated with all Legacy exterior acrylic topcoats and Tuff Cote WB Enamels. Safe for collection of potable water when topcoated. Can be left for up to 6 months before overcoating, as the Primer will not harden and require sanding.
LIMITATIONS	Areas showing high levels of red rust may require additional priming. Do not apply if the air and surface temperature during application and drying is likely to fall below 10°C.
TECHNICAL DATA	Resin: Alkyd Product Type: Oilbase Anticorrosive Primer Solvent: Mineral Turps Appearance: Light Grey Colour: Mid Grey Primer: Not applicable Durability: Excellent Thinning and Clean Up: Mineral Turpentine Pack Size: 04, .10 Vol Solids: 50 percent Touch Dry: 15 minutes @20°C Recoat Time: Overnight @20°C Max Recoat Time: > 6 months Number of Coats: 1 Theoretical Coverage: 10 m ² /litre/coat Wet Film Thickness: 140 microns Dry Film Thickness: 70 microns
AVAILABLE FINISHES @60°C	Sheen Low Sheen
SPREAD RATE	First Coat: 10 - m ² /litre/coat Practical spreading rates will vary depending on such factors as application method, ambient conditions and surface porosity and roughness.
PRODUCT CODES	55-720UP.04 55-720UP.10

SURFACE PREPARATION Galvanised Steel and Zincalume-Aged Unpainted Good

If any areas of moss or mould infestation exist, treat them with TRUEPREP GREEN KILL, following instructions on TDS. Apply by flood coating to the surface and allow a minimum of 48 hours and up to four weeks for sterilization before scrubbing or water-blasting for removal of the detritus. For heavy infestations, longer dwell time or additional applications may be required.

Clean down using TRUEPREP SURFACE CLEAN applying by pump spray or broom. Additional scrubbing will assist in the breakdown and removal of any difficult contamination. Refer to TDS for application and dilution rates. Water blast or thoroughly rinse with high volume water to remove all dirt, grease and surface contamination.

Inspect the substrate prior to applying any coating system to ensure there are no surface defects exists. Repair as required.

All areas of rust or corrosion must be abraded using wire brushes, sandpaper, or Ultra-high pressure water blast to remove so little or no corrosion is left on the surface. Treat the entire surface TRUEPREP RUST KILL to remove residual rust, white rust and remaining surface contaminants and clean the metal prior to painting. Rinse clean as per manufacturers recommendations. If the substrate is not passivated in this way, it is likely that corrosion will occur under the new paint film.

When dry immediately apply specified coating system to prevent any contamination or further corrosion.

Galvanised Steel and Zincalume-Aged Unpainted Poor

If any areas of moss or mould infestation exist, treat them with TRUEPREP GREEN KILL, following instructions on TDS. Apply by flood coating to the surface and allow a minimum of 48 hours and up to four weeks for sterilization before scrubbing or water-blasting for removal of the detritus. For heavy infestations, longer dwell time or additional applications may be required.

Clean down using TRUEPREP SURFACE CLEAN applying by pump spray or broom. Additional scrubbing will assist in the breakdown and removal of any difficult contamination. Refer to TDS for application and dilution rates. Water blast or thoroughly rinse with high volume water to remove all dirt, grease and surface contamination.

Inspect the substrate prior to applying any coating system to ensure there are no surface defects exists. Repair as required.

All areas of rust or corrosion must be abraded using wire brushes, sandpaper, or Ultra-high pressure water blast to remove so little or no corrosion is left on the surface. Treat the entire surface TRUEPREP RUST KILL to remove residual rust, white rust and remaining surface contaminants and clean the metal prior to painting. Rinse clean as per manufacturers recommendations. If the substrate is not passivated in this way, it is likely that corrosion will occur under the new paint film.

Check to ensure all rusted areas have been passivated to a clean rust-free surface. If not repeat the treatment to affected areas.

When dry immediately apply Specified Primer to prevent any contamination or further corrosion.

Galvanised Steel and Zincalume-New Unpainted

Clean down using TRUEPREP SURFACE CLEAN by pump spray or brush. Additional scrubbing will assist in the breakdown and removal of any difficult contamination. Refer to TDS for application and dilution rates. Water blasting to remove all dirt, grease and contaminants.

Inspect the substrate prior to applying the first coat to ensure there is no contamination remaining and no surface defects exists. If there is either contaminants or defects are present, rectification process is required prior to any coating being applied.

All Laps and exposed overhangs, including those over guttering should be primed (or double primed if within 500m of the sea) before installation. These areas do not receive any rain-washing once installed and windblown salts and other contaminants lodge there. These are always the first areas of the roof to corrode.

Apply paint system immediately to prevent any contamination or further corrosion.

COATING TECHNOLOGIES LIMITED

10 Andromeda Crescent, East Tamaki, Auckland 2013 Ph +64 9 837 0897 www.cotec.co.nz

Technical information given verbally or in writing is based on knowledge and research, given in good faith and believed to be reliable, but no guarantee of accuracy is made or implied. Since methods and conditions of use are beyond our control, all merchandise is sold and received subject to the condition that our liability whether express or implied for any defect in quality, or for any lack of fitness for the specified use thereof, is limited to the return of the purchase price if written claim is made within 14 days from the date of delivery. It is recommended that the user makes his or her own tests to determine the suitability of the product for his own requirements. Freedom from patent restrictions is not implied.

Galvanised Steel and Zinalume-Previously Painted Good

If any areas of moss or mould infestation exist, treat them with TRUEPREP GREEN KILL, following instructions on TDS. Apply by flood coating to the surface and allow a minimum of 48 hours and up to four weeks for sterilization before scrubbing or water-blasting for removal of the detritus. For heavy infestations, longer dwell time or additional applications may be required.

Clean down using TRUEPREP SURFACE CLEAN applying by pump spray or broom. Additional scrubbing will assist in the breakdown and removal of any difficult contamination. Refer to TDS for application and dilution rates. Water blast or thoroughly rinse with high volume water to remove all dirt, grease and surface contamination.

Inspect the substrate prior to applying any coating system to ensure there are no surface defects exists. Repair as required.

Perform a crosscut adhesion test to several places across all elevations where existing coating are present to validate adhesion of the existing coating prior to overcoating. It is also recommended to apply TEST AREAS of the specified paint system to several places across all elevations to validate adhesion of the system AND mitigate risk of blistering that may occur between bare galvanised iron and the factory applied primer, or previous coatings. Contact Cotec Technical if you have any concerns, or reference MPNZA fact sheet #44.

Any areas of rust or corrosion or where original coating is through to the metal, must be abraded using wire brush, sandpaper, or Ultra-high pressure water blast to remove so little or no corrosion is left on the surface. Treat the entire surface TRUEPREP RUST KILL to remove residual rust, white rust and remaining surface contaminants and clean the metal prior to painting. Rinse clean as per manufacturers recommendations. If the substrate is not passivated in this way, it is likely that corrosion will occur under the new paint film.

All areas must be free of loose or flaking paint, where the coating is eroded or powdery the surface must be abraded using wire brushes, sandpaper or high-pressure water blast to ensure the best adhesion of the new paint. Feather all edges.

Any areas that are shiny (original gloss level) such as shaded areas must be sanded to knock the gloss and provide a key.

Do not expect paint to successfully bridge gaps and cracks.
Apply coat one immediately to prevent any contamination or further corrosion.

COATING TECHNOLOGIES LIMITED

10 Andromeda Crescent, East Tamaki, Auckland 2013 Ph +64 9 837 0897 www.cotec.co.nz

Technical information given verbally or in writing is based on knowledge and research, given in good faith and believed to be reliable, but no guarantee of accuracy is made or implied. Since methods and conditions of use are beyond our control, all merchandise is sold and received subject to the condition that our liability whether express or implied for any defect in quality, or for any lack of fitness for the specified use thereof, is limited to the return of the purchase price if written claim is made within 14 days from the date of delivery. It is recommended that the user makes his or her own tests to determine the suitability of the product for his own requirements. Freedom from patent restrictions is not implied.

Galvanised Steel and Zinalume-Previously Painted Poor

If any areas of moss or mould infestation exist, treat them with TRUEPREP GREEN KILL, following instructions on TDS. Apply by flood coating to the surface and allow a minimum of 48 hours and up to four weeks for sterilization before scrubbing or water-blasting for removal of the detritus. For heavy infestations, longer dwell time or additional applications may be required.

Clean down using TRUEPREP SURFACE CLEAN applying by pump spray or broom. Additional scrubbing will assist in the breakdown and removal of any difficult contamination. Refer to TDS for application and dilution rates. Water blast or thoroughly rinse with high volume water to remove all dirt, grease and surface contamination.

Inspect the substrate prior to applying any coating system to ensure there are no surface defects exists. Repair as required.

Generally, poorly adhered coatings will be required to be removed prior to painting.

Perform a crosscut adhesion test to several places across all elevations where existing coating are present to validate adhesion of the existing coating prior to overcoating. It is also recommended to apply TEST AREAS of the specified paint system to several places across all elevations to validate adhesion of the system AND mitigate risk of blistering that may occur between bare galvanised iron and the factory applied primer, or previous coatings. Contact Cotec Technical if you have any concerns, or reference MPNZA fact sheet #44.

Any areas of rust or corrosion or where original coating is through to the metal, must be abraded using wire brush, sandpaper, or Ultra-high pressure water blast to remove so little or no corrosion is left on the surface. Treat the entire surface TRUEPREP RUST KILL to remove residual rust, white rust and remaining surface contaminants and clean the metal prior to painting. Rinse clean as per manufacturers recommendations. If the substrate is not passivated in this way, it is likely that corrosion will occur under the new paint film.

All areas must be free of loose or flaking paint, where the coating is eroded or powdery the surface must be abraded using wire brushes, sandpaper or high-pressure water blast to ensure the best adhesion of the new paint. Feather all edges.

Any areas that are shiny (original gloss level) such as shaded areas must be sanded to knock the gloss and provide a key.

Do not expect paint to successfully bridge gaps and cracks.
Apply coat one immediately to prevent any contamination or further corrosion.

Any badly rusted sections of Galvanised steel should be replaced.

APPLICATION	Excellent adhesion to Galvanised Steel and Zinalume. Suitable for use over lightly rusted Galvanised steel and Zinalume. Overcoated with all Legacy exterior acrylic topcoats and Tuff Cote WB Enamels. Safe for collection of potable water when topcoated.
--------------------	--

THINNING	Mineral Turps
-----------------	---------------

ENVIRONMENTAL	This formulation uses the latest technology with low toxicity, ensuring environmental issues are not compromised. DO NOT POUR paint or wash down storm water or water courses. ALWAYS dispose of in accordance with local Government regulations. Soak up spills with absorbent material and dispose of properly. If spraying use suitable respiratory protection. Refer to the MATERIAL SAFETY DATA SHEET
----------------------	--

COATING TECHNOLOGIES LIMITED

10 Andromeda Crescent, East Tamaki, Auckland 2013 Ph +64 9 837 0897 www.cotec.co.nz

Technical information given verbally or in writing is based on knowledge and research, given in good faith and believed to be reliable, but no guarantee of accuracy is made or implied. Since methods and conditions of use are beyond our control, all merchandise is sold and received subject to the condition that our liability whether express or implied for any defect in quality, or for any lack of fitness for the specified use thereof, is limited to the return of the purchase price if written claim is made within 14 days from the date of delivery. It is recommended that the user makes his or her own tests to determine the suitability of the product for his own requirements. Freedom from patent restrictions is not implied.